

2008 European Air Suspension Application List

 Semi Air Kit

 Coil Rite Kit

 Full Air Kit

 LSV Kit

Audi	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
A6	98-07	Coil Rite Kit			4105	6013

Chrysler	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
PT Cruiser	01-08	Coil Rite Kit			4139	6015

Citroen	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Dispatch - Jumpy	96-06	Coil Rite Kit			4143	6016
Dispatch - G9	07-08	Coil Rite Kit			4264	6016
Dispatch - Jumpy	96-06	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3150	9000
Dispatch - Jumpy	96-06	Full Air Kit - Electronic Height Control - With Lowering			3260	9000
Dispatch - G9	07-08	Full Air Kit - Electronic Height Control - With Lowering			3496	9015
C25 - Euro Chassis 280/290	88-93	For All Applications			2112	6781
C25 - Euro Chassis 280/290	88-93	LSV Kit For Non-ABS Vehicles			3003	3000
C25 - Euro Chassis 280/290	88-93	LSV Linkage For Non-ABS Vehicles (Motorhomes)			3149	Link
Jumper / Relay - Euro Chassis X230	94-01	For All Applications			2110	6781
Jumper / Relay - Euro Chassis X230	94-01	LSV Kit For Non-ABS Vehicles			3003	3000
Jumper / Relay - Euro Chassis X230	94-01	LSV Linkage For Non-ABS Vehicles (Motorhomes)			3149	Link
Jumper / Relay - Euro Chassis X244	02-06	For All Applications			2110	6781
Jumper / Relay - Euro Chassis X244	02-06	LSV Kit For Non-ABS Vehicles			3178	Cylinder
Jumper/ Relay - Euro Chassis X250	06-08	Standard kit to suit all applications			2428	6781
Jumper / Relay - Euro Chassis X250	06-08	Kit with larger Air Springs for extra volume and comfort			2429	7339

Diahatsu	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Rocky	00-07	Coil Rite Kit			4580	4580

Fiat	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Scudo	96-06	Coil Rite Kit			4143	6016
Scudo - G9	07-08	Coil Rite Kit			4264	6016
Scudo	96-06	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3150	9000
Scudo	96-06	Full Air Kit - Electronic Height Control - With Lowering			3260	9000
Scudo-G9	07-08	Full Air Kit - Electronic Height Control - With Lowering			3496	9015
Doblo Cargo	03-08	No Anti-Roll Bar			2114	6781
Doblo Panorama	03-08	With Anti-Roll Bar (Passenger Vehicle Only)			2117	7073
Ducato - Euro Chassis 280/290	88-93	For All Applications			2112	6781
Ducato - Euro Chassis 280/290	88-93	LSV Kit For Non-ABS Vehicles			3003	3000
Ducato - Euro Chassis 280/290	88-93	LSV Linkage For Non-ABS Vehicles (Motorhomes)			3149	Link
Ducato - Euro Chassis X230	94-01	For All Applications			2110	6781
Ducato - Euro Chassis X230	94-01	LSV Kit For Non-ABS Vehicles			3003	3000
Ducato - Euro Chassis X230	94-01	LSV Linkage For Non-ABS Vehicles (Motorhomes)			3149	Link
Ducato - Euro Chassis X244	02-06	For All Applications			2110	6781
Ducato - Euro Chassis X244	02-06	LSV Kit For Non-ABS Vehicles			3178	Cylinder
Ducato - Euro Chassis X250	06-08	Standard kit to suit all applications			2428	6781
Ducato - Euro Chassis X250	06-08	Kit with larger Air Springs for extra volume and comfort			2429	7339

Ford	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Ranger	00-08	4x4-For Vehicles Fitted with ABS			3454	6781
Transit 100/120	89-99	Transit Square Axle without Anti Roll Bar			2123	0335
Transit 130/160/190	89-99	Transit Round Axle without Anti Roll Bar			3001	0335
Transit LSV 100/120/130/160/190	89-99	All Models 100/120/130/160/190			3000	9019
Transit	00-03	Transit Square Axle Single Rear Wheel - ABS Vehicles only			3450	6781
Transit	00-03	Transit Round Axle Single Rear Wheel - ABS Vehicles only			3451	6781
Transit	00-08	Transit Round Axle Dual Rear Wheel - ABS Vehicles only			3448	6781
Transit	04-08	Front Wheel Drive / Square Rear Axle (Type 330-350)			3446	6397
Transit	04-08	Front Wheel Drive / Square Rear Axle (Type 260-300)			3449	6397
Transit FT350	04-08	Rear Wheel Drive / Round Rear Axle			3447	6397

Honda Vans	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Odyssey	99-08	Coil Rite Kit			4138	6017
Odyssey	96-98	Coil Rite Kit			4133	6018

Honda SUVs	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Passport	98-02	4x2, 4x4			4136	6014
Pilot	01-06				4138	6017

Hummer SUVs	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
H2, H2 SUT (With Rear Coil Springs)	03-08	Coil Rite Kit			4108	6003

Hyundai SUVs	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Santa-Fe	07-08	Coil Rite Kit			4170	6017
Santa-Fe	01-06	Coil Rite Kit			4167	6027
Terracan	01-07	Coil Rite Kit			4124	6007

Hyundai Vans	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Veracruz	07-08	Coil Rite Kit			4170	6017

Isuzu	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Oasis	96-98	Coil Rite Kit			4133	6018
Amigo	98-00	Coil Rite Kit			4103	6014
Axiom	02-03	Coil Rite Kit			4136	6014
Rodeo, Rodeo Sport	98-04	Coil Rite Kit			4136	6014
Trooper	98-02	4x4 Leaf Spring vehicle with ABS			3460	6781
Trooper	98-04	Coil Rite Kit			4143	6016
Trooper	92-97	Coil Rite Kit			4106	6015
D-MAX / Rodeo	03-08	4x4 Leaf Spring vehicle with ABS			3460	6781
NPR	96-08	Front Axle Kit	2440	6868		

Iveco	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Daily 35-10, 35-12, 45-10, 45-12	90-99	Light Duty Application			2089	6781
Daily 35-10, 35-12, 45-10, 45-12	90-99	LSV Kit For Non-ABS Vehicles			3082	3000
Daily 35-10 to 49-12,	90-99	All Applications-Twin Rear Wheel (With ABS) - 4 Bag System			3455	9000
Daily 35C-11 to 35C-13,	00-06	Twin Rear Wheel (With ABS) - 4 Bag System			3456	9000
Daily 35C to 50C	06-08	Twin Rear Wheel (With ABS)			3410	0335
Daily 40C-13, 50C-13,	00-06	Twin Rear Wheel (With ABS) - 4 Bag System			3456	9000
Daily 35S-L 11 To 17	00-06	Single rear wheel (Leaf Below Axle)			3438	6397
Daily 29-35 S-L 11 To 18	00-08	Single rear wheel (Leaf Above Axle)			3439	6781

Jeep	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Commander	06-08	4x2 / 4x4			4157	6005
Grand Cherokee	05-08	4x2 / 4x4			4157	6005
Grand Cherokee	92-98	4x2 / 4x4			4118	6018
Grand Wagoneer	92-98	4x2 / 4x4			4118	6018
Liberty	02-08	4x2 / 4x4			4146	6005
Summit	92-93	Coil Rite Kit			4105	6013
Wrangler X	07-08	4x2 / 4x4			4173	6006
Wrangler Sahara	07-08	4x2 / 4x4			4173	6006
Wrangler Rubicon	07-08	4x4 Only			4172	6007
Wrangler Unlimited X	07-08	4x2 / 4x4			4173	6006
Wrangler Unlimited Sahara	07-08	4x2 / 4x4			4173	6006
Wrangler Unlimited Rubicon	07-08	4x4 Only			4172	6007
Wrangler	07-08	4x2 / 4x4			4157	6005

Kia Vans	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Sodona	06-08	Coil Rite Kit			4138	6017

Kia SUVs	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Sorento	03-08	Coil Rite Kit			4153	6024

Land Rover	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Defender 90	90-97	Coil Rite Kit			4121	6003
Defender 110	83-08	Coil Rite Kit			4510	6010
Discovery	90-04	Coil Rite Kit			4121	6003
Range Rover	90-96	Coil Rite Kit			4121	6003
Range Rover 93MY, HSE 97MY	95-08	OEM-Original Landrover Suspension- Replacement Bags	OEM	0200	OEM	0027

Lexus	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
LX 450	96-98	Coil Rite Kit			4124	6007
LX 470	99-08	Coil Rite Kit			4124	6007

Mazda	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
626	79-82				4591	6591
Mazda5	06-08				4168	6027
Mazda6	06-08				4168	6027
MPV	05-06	Coil Rite Kit			4140	6018
MPV Van	96-98	Coil Rite Kit			4105	6013
B2500/ BT-50	00-08	4x4-For Vehicles Fitted with ABS			3454	6781
Pickup	72-90	4x2			1130**	0335

Mercedes	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Vito	96-03	Front Wheel Drive Vehicle			4145	6028
Vito	03-08	Rear Wheel Drive Vehicle			4261	6016
Vito	03-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3489	9232
Vito	03-08	Full Air Kit - Electronic Height Control - With Lowering			3487	9232
3 Series Sprinter - 207 - 310	88-96	For All Applications			3004	6781
3 Series Sprinter - 308, 310, 312, 313, 316	96-06	Chassis Cab / Motorhome Application			3114	9000
3 Series Sprinter - 308, 310, 312, 313, 316	96-06	All Applications			2312	9002
Sprinter 209, 211, 213, 215	06-08	ABS Vehicles Only			2447	6397
Sprinter 309, 311, 313, 315, 318, 324	06-08	ABS Vehicles Only			2447	6397
4 Series Sprinter - 408, 410, 412, 413, 416	96-06	Chassis Cab Version (using 70mm sleeve airsprings)			3119	7095
4 Series Sprinter - 408, 410, 412, 413, 416	96-06	Chassis Cab Version (using double convolute airsprings)			2382	6397
4 Series Sprinter - 408, 410, 412, 413, 416	96-06	Van Version (using 70mm sleeve airsprings)			3461	7095
4 Series Sprinter - 408, 410, 412, 413, 416	96-06	Van Version (using double convolute airsprings)			2425	6397
Sprinter 509, 511, 515, 518, 524	06-08	ABS Vehicles Only			2455	6781
6 Series Sprinter - 616	96-08	4 Bag System			3466	6781

Mitsubishi	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Expo	92-93	Coil Rite Kit			4105	6013
Montero Sport	99-04	Coil Rite Kit			4137	6007
Pajero / Shogun	93-03	Coil Rite Kit			4113	6007
Pajero	04-08	Coil Rite Kit			4247	6014
Pickup	69-96	4x2			1130**	0335
L200	90-05	4x4-For Vehicles Fitted with ABS			3457	6781
L200 / Triton / Warrior	06-08	4x4-For Vehicles Fitted with ABS			3469	6781

Nissan	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Quest	04-08	Coil Rite Kit			4118	6018
Murano	03-08	4x2 / 4x4			4118	6018
Pathfinder Armada	04-05	4x2 / 4x4			4150	6023
Pathfinder	87-95	4x2 / 4x4			4106	6015
Pathfinder	06-08	4x2 / 4x4			4166	6021
Frontier	01-04	4x2			2293	9002
Frontier	05-08	4x2/4x4			2403	6766
Xterra	05-08	4x2 / 4x4			2409	9002
Pickup	69-96	4x2			1130**	0335
Terrano	92-04	Coil Rite Kit			4106	6015
Titan	04-08	4x2, 4x4			2355	6781
Patrol	88-94	Leaf Spring 4x2			1130	0335
Patrol	93-08	Coil Rite Kit			4570	6010
D21, D22, Navara	98-04	4x4-For Vehicles Fitted with ABS			3458	0335
D40, Navara	05-08	4x4-For Vehicles Fitted with ABS			2413	6397
Primastar X83	01-08	Coil Rite Kit			4250	6021
Primastar X83	01-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3465	9232
Primastar X83	01-08	Full Air Kit - Electronic Height Control - No Lowering			3244	9232
Primastar X83	01-08	Full Air Kit - Electronic Height Control - With Lowering			3166	9232
Primastar X83	01-08	LSV Kit For Non-ABS Vehicles			3334	Cylinder
Interstar X70	98-08	Semi Air Heavy Duty Kit	4117	6004	3123	6784
Interstar X70	98-08	Complete with Automatic Height Control	4117	6004	3121	9000
Interstar X70	98-08	Rear Axle Only - Tapered Sleeve Kit	4117	6004	3126	9000
Interstar X70	98-08	LSV Kit For Non-ABS Vehicles			3148	
Interstar X70	98-08	Full Air Kit - Front Axle	3382	2119		
ECO T100	03-06	All Applications			3471	0335
Atleon LP2 35.15-35HD.15-56.15	06-08				3406	6784
Atleon LG1 70.14-80.14-80.19	06-08				3371	6183
Cabstar	06-08				3127	6784
Trade	03-06	All Applications			3474	0335

Opel	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Campo	88-08	4x4 Campo - Fitted with ABS			3460	6781
Vivaro X83	01-08	Coil Rite Kit			4250	6021
Vivaro X83	01-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3465	9232
Vivaro X83	01-08	Full Air Kit - Electronic Height Control - No Lowering			3244	9232
Vivaro X83	01-08	Full Air Kit - Electronic Height Control - With Lowering			3166	9232
Vivaro X83	01-08	LSV Kit For Non-ABS Vehicles			3334	
Movano X70	98-08	Semi Air Heavy Duty Kit	4117	6004	3123	6784
Movano X70	98-08	Complete with Automatic Height Control	4117	6004	3121	9000
Movano X70	98-08	Rear Axle Only - Tapered Sleeve Kit	4117	6004	3126	9000
Movano X70	98-08	LSV Kit For Non-ABS Vehicles			3148	
Movano X70	98-08	Full Air Kit - Front Axle	3382	2119		

Peugeot	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
307	04-08	Coil Rite Kit			4158	6262
Expert	96-06	Coil Rite Kit			4143	6016
Expert - G9	07-08	Coil Rite Kit			4264	6016
Expert - G9	07-08	Full Air Kit - Electronic Height Control - With Lowering			3496	9015
J5 - Euro Chassis 280/290	88-93	For All Applications			2112	6781
J5 - Euro Chassis 280/290	88-93	LSV Kit For Non-ABS Vehicles			3003	3000
J5 - Euro Chassis 280/290	88-93	LSV Linkage For Non-ABS Vehicles (Motorhomes)			3149	Link
Boxer - Euro Chassis X230	94-01	Commercial Vehicle Application			2110	6781
Boxer - Euro Chassis X230	94-01	LSV Kit For Non-ABS Vehicles			3003	3000
Boxer - Euro Chassis X230	94-01	LSV Linkage For Non-ABS Vehicles (Motorhomes)			3149	Link
Boxer - Euro Chassis X244	02-06	Commercial Vehicle Application			2110	6781
Boxer - Euro Chassis X244	02-06	LSV Kit For Non-ABS Vehicles			3178	Cylinder
Boxer - Euro Chassis X250	06-08	Standard kit to suit all applications			2428	6781
Boxer - Euro Chassis X250	06-08	Kit with larger Air Springs for extra volume and comfort			2429	7339

Renault	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Espace	00-02	Coil Rite Kit			4251	6017
Espace	03-08	Coil Rite Kit			4250	6021
Espace	01-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3172	9015
Espace	01-08	Full Air Kit - Electronic Height Control - With Lowering			3490	9015
Laguna II	02-03	Coil Rite Kit			4106	6015
Trafic X83	01-08	Coil Rite Kit			4250	6021
Trafic X83	01-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3465	9232
Trafic X83	01-08	Full Air Kit - Electronic Height Control - No Lowering			3244	9232
Trafic X83	01-08	Full Air Kit - Electronic Height Control - With Lowering			3166	9232
Trafic X83	01-08	LSV Kit For Non-ABS Vehicles			3334	Cylinder
Mascot	05-08				3125	6784
Master X70	98-08	Semi Air Heavy Duty Kit	4117	6004	3123	6784
Master X70	98-08	Complete with Automatic Height Control	4117	6004	3121	9000
Master X70	98-08	Rear Axle Only - Tapered Sleeve Kit	4117	6004	3126	9000
Master X70	98-08	LSV Kit For Non-ABS Vehicles			3148	Cylinder
Master X70	98-08	Full Air Kit - Front Axle	3382	2119		
Master X70	98-03	Full Air Improvement Comfort Kit	4117	6004	3141	9015
Maxity	07-08				3127	6784

Ssangyong SUVs	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Rexton/Actyon	02-08	Coil Rite Kit			4103	6014
Musso Sport	04-06	Coil Rite Kit			4240	6015
Musso Wagon	92-06	Coil Rite Kit			4135	6024

Suzuki	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Vitara	90-00	Coil Rite Kit			4620	3624
Jimny	06-08	Coil Rite Kit	4515	4515	4516	4516
Sidekick	89-93	Coil Rite Kit			4620	3624

Toyota Cars	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
ECHO	01-05	Coil Rite Kit			4118	6018
Yaris	07-08	Coil Rite Kit			4136	6014

Toyota	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Dyna 100, 150	02-08				3128	0335
Siena	04-08	Coil Rite Kit			4155	6020
Siena	98-03	Coil Rite Kit			4118	6018
RAV4	07-08	Coil Rite Kit			4174	6028
RAV4	96-98	Coil Rite Kit			4104	6012
FJ Cruiser	07-08	Coil Rite Kit			4135	6024
4-Runner	90-95	Coil Rite Kit			4112	6006
4-Runner	96-97	Coil Rite Kit			4123	6021
4-Runner	98-08	Coil Rite Kit			4135	6024
Sequoia	01-07	Coil Rite Kit			4124	6007
Landcruiser	91-08	Coil Rite Kit (European Model)			4124	6007
Landcruiser (100 Series)	98-07	Coil Rite Kit			4114	6008
Landcruiser (200 Series)	07-08	Coil Rite Kit			4129	6010
Landcruiser	88-96	Leaf Spring Vehicle - BJ75 Pick-up			1130	0335
Hiace	99-02	Coil Rite Kit			4500	3600
Hiace	03-08	Coil Rite Kit			4138	6017

Toyota (Cont)	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Hilux	88-05	4 x 4 N16 / N17 - For Vehicles Fitted With ABS			3459	6781
Hilux / Vigo	06-08	4 x 4			3475	0335
Hilux / Vigo	06-08	LSV Kit			3452	3008
Pickup	69-95	4x2			1130**	0335
Pickup	84-95	4x4			2116	6781
T 100	93-98	4x2			2115	6781
T 100	93-98	4x4			2116	6781
Tacoma	95-04	4x2			2213	6959
Tacoma	05-08	4x2			2410	6959
Tacoma	95-04	4x4			2304	6781
Tacoma Prerunner	05-08	4x2 only			2407	6781
Tacoma Prerunner	95-04	4x2 only			2304	6781
Tundra	07-08	4x2, 4x4			2445	6397
Tundra	00-05	4x2			2212	9001
Tundra	00-05	4x4			2245	6781
Tundra	00-05	4x4 (TRD) 4x2			2245	6781
Van with rear Coils	64-89	Coil Rite Kit			4112	6006

Vauxhall	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Vivaro X83	01-08	For Use with Original Coil			4250	6021
Vivaro X83	01-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3465	9232
Vivaro X83	01-08	Full Air Kit - Electronic Height Control - No Lowering			3244	9232
Vivaro X83	01-08	Full Air Kit - Electronic Height Control - With Lowering			3166	9232
Vivaro X83	01-08	LSV Kit For Non-ABS Vehicles			3334	Cylinder
Movano X70	98-08	Semi Air Heavy Duty Kit	4117	6004	3123	6784
Movano X70	98-08	Complete with Automatic Height Control	4117	6004	3121	9000
Movano X70	98-08	Rear Axle Only - Tapered Sleeve Kit	4117	6004	3126	9000
Movano X70	98-08	LSV Kit For Non-ABS Vehicles			3148	Cylinder
Movano X70	98-08	Full Air Kit - Front Axle	3382	2119		

Volkswagen Cars	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Eos, GTI	07-08	Coil Rite Kit			4176	6027
Passat Wagon, Jetta	07-08	Coil Rite Kit			4175	6026
Passat Wagon, Jetta	00-06	Coil Rite Kit			4104	6003

Volkswagen Vans	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
Caddy Pickup (Skoda)	98-08	Coil Rite Kit			4144	6026
Taro (4x4)	88-04	N16 / N17 - For Vehicles fitted with ABS			3459	6781
Euro Van, T-4	85-03	Coil Rite Kit			4117	6004
Euro Van, T-4	85-03	Full Air Kit - Rear Axle Kit only			3022	6988
T5 Van / Bus	04-08	Full Air Kit - Rear Axle Kit only			3482	6988
T5 Van / Bus	04-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3498	6988
T5 Van / Bus	04-08	Full Air Kit - Electronic Height Control - With Lowering			3483	6988
T5 Chassis Cab	04-08	Full Air Kit - Rear Axle Kit only			3481	6988
T5 Chassis Cab	04-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers			3499	6988
T5 Chassis Cab	04-08	Full Air Kit - Electronic Height Control - With Lowering			3484	6988
T5 Van / Bus	04-08	Full Air Kit - Front Axle - 2.8 Tonne Vehicle - 1540 Kg Front Axle Load	5506			
T5 Van / Bus / Chassis	04-08	Full Air Kit - Front Axle - 3.2 Tonne Vehicle - 1710 Kg Front Axle Load	5507			
3 Series LT	96-06	Chassis Cab / Motorhome Application			3114	9000
3 Series LT	96-06	All Applications			2312	9002
Crafter 28 - 35	06-08	ABS Vehicles Only			2447	6397
4 Series LT	96-06	Chassis Cab Version (using 70mm sleeve airsprings)			3119	7095
4 Series LT	96-06	Chassis Cab Version (using double convolute airsprings)			2382	6397
4 Series LT	96-06	Van Version			2425	6397
Crafter 35 - 50	06-08	ABS Vehicles Only			2455	6781

Volvo	YEAR	NOTES	Front Kit	Air Spring	Rear Kit	Air Spring
140,160	66-74	Coil Rite Kit			4101	6002
240,260	75-85	Coil Rite Kit			4106	6015
850	90-01	Coil Rite Kit			4105	6013

For Vehicles fitted with ESP (Electronic Stability Program) it is necessary to turn it off once our kits are installed.. This can be carried out at your nearest dealer.